



Monitoring the Calls

(Call Monitoring in Hunting Group) [KX-T7536, KX-T7235 only]

You can monitor the information of incoming outside calls waiting in the extension groups and confirm how the calls have been treated. Up to eight extension users can monitor simultaneously.

◆ To monitor

T7536 / T7235

While on-hook

Press **SHIFT** until "MNTR" is displayed. → Press "MNTR". → Enter specific **group no.** (01-32) or ****** for all. → Press "DISP".

If you enter a group number except UCD/Ring/No Replay group* number or "0", you hear the error tone. Re-enter the proper number.

Information sample

Group 02	Waiting 002	Group no. (01-32, (**: all)) / Waiting calls (000-255)
Total Arrived	00020	Total of received calls (00000-65535)
Total Answered	00010	Total of answered calls (00000-65535)
Total OVF/IRNA	00002	Total of transferred calls (00000-65535)
Total Lost	00002	Total of disconnected waiting calls (00000-65535)
MENU	CLR	MNTR



- When receiving a call, the monitoring display also remains with the flashing CO button and ringing.
- When entering ** for all, total calls of all groups is displayed.
- When the night mode is switched to the day mode, "Total Call" can be cleared automatically by programming. For more details, consult your manager or dealer.
- *For more details about these groups, consult your manager or dealer.



- To return to the initial display, press the MENU button or go off-hook and on-hook.
- To go to the next/previous group number, rotate the Jog Dial or press the UP/DOWN button instead of entering the group number. In this case, all group number "**" is not displayed.

◆ To clear the number of calls

T7536 / T7235

Press "CLR". → Press "Yes".

Information sample

Group 02	Waiting 002	
Total Arrived	00020	
Total Answered	00010	
Total OVF/IRNA	00002	
Total Lost	00002	
MENU	CLR	MNTR